

DeoxIT[®] Gold GxMD

DeoxIT[®] Gold Vacuum Tube SURVIVAL KIT

CONTENTS:

DeoxIT[®] Rejuvenator, 100% solution, 25 mL bottle, #D100L-25C
DeoxIT[®] GOLD GX-MD, 100% solution, 7.4 mL bottle, #GXMD-2DB
Lint Free Cloth Squares, cotton, 12 each, #LFC-C
Soaking Cups, 2 each
Foam Swabs, 2 each, #SWP
Socket Cleaning Brushes (black plastic), Large, 2 each, #AB
Socket Cleaning Brush (metal wire), 1 each, #B-SS116



12200 Thatcher Court
Poway, CA 92064 USA
TEL: 858/486-8388
Email: info@caig.com
Web: www.caig.com

DIRECTIONS:

1. Verify that system is off and unplug power.
2. Remove Vacuum Tubes.
3. Apply the DeoxIT[®] D100L Solution using the cleaning brushes to the inside of the tube sockets.
4. Place enough DeoxIT[®] D100L Solution in cups (included in kit) to permit tube posts to fully submerge in liquid without wetting the upper portion of the tube.
5. Stand vacuum tubes in cups and allow to sit overnight.
6. Wipe off DeoxIT[®] and contaminants with Large Foam Swabs.
7. Apply the DeoxIT[®] GOLD GxMD Solution using the cleaning brushes to the inside of the tube sockets.
8. Remove the vacuum tubes from the cups and clean the edges using the foam swabs and lint free cloth.
9. Replace the vacuum tubes.

Assembled in U.S.A. with
foreign & domestic parts.

**Part No.
SK-GXMD**

